

Water Meter Instructions

Screen display #	Numbers are bottom left of screen / press yellow arrow to move between screens
#1: Totalizer 1:	<p>Total water used (ML) Additional Information: <i>fault</i> icon is top left of screen - in case of fault, triangle with exclamation mark appears <i>no water</i> icon is top middle of screen - in case of no water, porthole & wave appear <i>battery</i> icon is top right of screen - indicates level of charge</p>
#2: Totalizer 2:	<p>Total reverse flow (ML) Additional Information: <i>reverse totalizer</i> should show zero - if not, attention is required</p>
#3: Flow Rate	Actual flow rate (ML/day)
#4: Fault Code	<p>Flashes between fault code and fault hours Additional Information: <i>fault code</i> flashing continuously - attention is required</p>
#5: Totalizer 3/Reset Date	<p>Flashes between total water use (ML) & reading start date Additional Information: - can be reset to zero at any time - to re-set, press and hold the black arrow in the yellow square; number 5 will flash then R will flash; release the button and screen will be reset; screen will alternate between the reset date and the total from last re-set</p>
#6: Display Test	Shows all the display features
Additional Screen	Some meters have additional icons - removed on request
Reset call up screen	Not in use - cannot be removed

For faults or further information please contact the BIL office